

Standard Royal Orangerie

Please call Exaco for measurements if you have a custom greenhouse.

Notes:

- Do not set anchors in concrete until the entire greenhouse frame is complete, level and square. You will need some play to attach the uprights.
- It is recommended to build your foundation down to the frost line in your area and/or consult a local contractor for recommendations.
- Greenhouse base frame is 2.25" wide
- Corner anchor posts are 1.5" x 1.5". They attach at the interior corners of the base frame, then extend 12" below ground. Bolts attach to the bottom of the anchor to be a "catch" in the concrete. We recommend leaving a 4 to 6" hole in your concrete for the anchor. Do not embed the corner anchors into concrete until the greenhouse structure is built, leveled and square.
- Embedding the corner anchor into concrete is the most secure method, although you may choose to trim them off, cut in half, and use as L brackets to attach to the greenhouse and foundation with the appropriate stainless steel screws (i.e. Tap Con screws for concrete)

A = 1+2+3 15'7 1/4"	1 829mm / 2'8 5/8"
	2 3098mm / 10'2"
	3 829mm / 2'8 5/8"
B = 4+5 12'10 5/8"	4 3098mm / 10'2"
	5 829mm / 2'8 5/8"

